

Scandic® rainwater system The optimal solution for all types of roofs





The advantages of the Scandic® rainwater system



Recommended for every roof

The Scandic rainwater system can be combined with any type of roof covering: ceramic, concrete or metal tile, bituminous shingles, corrugated sheet and long strip roofing.

The universality and quality of Scandic rainwater systems is proven by the thousands of projects where they were mounted, in different European markets.



Over 40 years of extensive outdoor testing

The outdoor tests at sites located worldwide ensure that GreenCoat products withstand the harshest weather conditions like wind, rain, snow, saltwater, ice, UV radiation, high humidity and storms.

Ensuring quality through real outdoor testing is a priority for SSAB Swedish steel supplier and, therefore, they go far beyond what is required by the EU regulations.



BIO Patented technology for greener living - GreenCoat®

The Scandic rainwater system lasts over time, reduces environmental impact and allow for greener living.

The GreenCoat paint feature a Bio-based Technology (BT) coating with a substantial portion of the traditional fossil part replaced by a bio-based component(rapeseed oil) – a patented SSAB technology – making them the only coatings on the market with a high bio-renewable content.



Durability and reliability in operation

The chemical composition of the paint is optimized for excellent resistance to UV and corrosive factors. The zinc layer protects against corrosion, the higher it is, the better the protection. The surface is slightly textured and the primer coat in the same color as the paint helps protect against mechanical wear and fine scratches appearing during handling or a installation will not be visible.



High performance machines

The continuous investments in production lines and latest professional equipment generation, in the development of products and mounting technologies, aim obtaining the best performing rainwater systems on the market.





Certified products

The elements of the rainwater system are produced in accordance with SR requirements EN 612:2006 and SR EN 1462:2006 within ROOFART SRL, company that implemented the quality management system SR EN ISO 9001:2015, with AEROQ certification no. 2318/2021. In addition, coated products SSAB brand paint complies with current REACH regulations and does not contain chrome-plated, being manufactured according to EN 10169 + A1.



PPC

The role of the rainwater system is to collect precipitation from the roof and to evacuate it at ground level or collection in external tanks or systems sewerage, to avoid possible infiltrations into the building structure or uncontrolled spillage in the yard, garden or other open space.

System components

JB - Gutter

BJ - Gutter joint

CU - Universal stop end

CJ - Gutter bracket

CJL - Long gutter bracket

CPU - Universal bracket

PPC - Bracket support

PPCR - Twisted bracket support

SJ - Gutter stabilizer

KIB/KEB - Internal/External 90°corners with brackets

EJ - Gutter joint element

PP - Overflow element 90°/180°

PC - Round hopper

PCD - Rectangular hopper

RA - Gutter outlet

CB - Downpipe bend 60°

PB - Intermediate downpipe

BU - Downpipe

BB - Downpipe holder

RB - Downpipe branch

EC - Rainwater diverter

MB - Downpipe connector

CE - Shoe 60°

RC - Drain connector

DEP - Decanter

Available sizes

mara of colours

Systems are available in two sizes: 125/87 and 150/100. Gutters with 125 mm diameter are recommended for small and medium sized homes, gutters with 150 mm diameter can be used in industrial buildings with a considerable roof area.



Class	Thickness	Coating	Model	Guarantee
Colored (SSAB steel)	min. 0.57mm zinc 275g/m ²	GreenCoat RWS Pro BT 35µm	Circular 125/87; 150/100mm	30 years corrosion; 15 years color
Zinc	min. 0.57mm zinc 275g/m²	-	Circular 125/87; 150/100mm	10 years corrosion
Copper	min. 0.50 mm 99% copper purity	-	Circular 125/87; 150/100mm	* lifetime

Range of colours		Chrome Anthro	Anthracite	acite Copper	Chocolate	Grev						
	Wine red	Oxide red	Brown Red	Green	grey	brown	brown	Brown	Jet Black	Pure white	Copper	Zinc
	RAL 3005	RAL 3009	RAL 3011	RAL 6020	RAL 7016	RAL 8004	RAL 8017	RAL 8019	RAL 9005	RAL 9010		

^{*} Differences are possible between colours shown and actual colours. Check out the sheet samples.

 $^{^{**}}$ Certain colours are available for special orders. Please ask for information by calling us +40 372 900 222.

Gutter JB

Designed to collect rainwater from the roof, the gutter is a basic element of the rainwater system Made of a pre-painted sheet with thickness of 0.55 mm and length of 3m Fixed to the eaves of the roof with gutter brackets or universal brackets

Gutter joint



Seals the connections between gutter - gutter and gutter - corner Manages the differences resulting from linear expansions of gutters under temperature oscillations Ribbed gasket for increased sealing

Gutter bracket

CJ



Is mounted on the rafter to support the gutter Stiffening profile for increased resistance to high loads Use the bending tool to bent the hooks and adjust them according to the slope of

Pressed base for stiffening

the roof

Long gutter bracket CJL



Has the same role as the gutter bracket The tailpiece is longer. It is recommended to be used in conjunction with covers made of ceramic tiles or concrete roof tiles

Universal bracket CPU



An optimal alternative to the gutter bracket. Universal - can be mounted directly on the fascia board or the rafter by using the bracket support Decreases up to 60% the system mounting time by

avoiding the need to take various measurements and the bending of gutter brackets Pressed base for stiffening

(Twisted) bracket support PPC/PPCR



Used to fix the universal bracket on the rafter Adjusts the gutter slope for water drainage to the downpipe, with predetermined gradations Includes a screw and a nut The twisted piece is fixed to the side of the rafter. When replacing the rainwater system, there is no need to remove the tiles

Gutter joint element EJ



Provides enhanced strength of the gutter - gutter connections Made of 0.55 mm galvanized

Universal stop end CU



Is mounted onto the gutter on both ends Tightly sealed profile due to internal gasket Do not use silicone sealant, given it could lead to the deterioration of the gasket over time Pressed stop end for reinforcement

Gutter stabilizer





Aims to provide an additional support to the gutter in case of large loads (for example: snow, ice) or due to other pressure that may deform the system

Internal/External 90° corners with brackets KIB/KEB



It is mounted on the interior/ exterior corners of the building, and connects two gutters

The included gutter brackets provide increased tightness to the rainwater system Made from a single piece of material

Round hopper PC



Provides water collection from the valley without eaves and directs it into the downpipe Is provided with double stiffening for better rigidity and strength

Rectangular hopper **PCD**



Has the same role as the round hopper The difference is the rectangular form, which allows it to meet specific design or architecture needs

Overflow element 90°/ 180°



PP 90° is mounted with the help of brackets directly on the corners PP 180° is mounted with the help of brackets directly on the gutters

Gutter outlet



The main element to connect the horizontal system (consisting of gutters) with the vertical system of water drainage to the ground (consisting of downpipes)

Downpipe bend CB



Joining element between the gutter outlet and the downpipe Useful for changing the direction of water drainage through the downpipe For easy assembly, the pipe bent is larger at the upper end

Downpipe/ Intermediate downpipe



Ensures the flow of water either into the drains or onto soil/ground.
The piece is adjusted at an end for easy combination with another downpipe Is fixed on the building wall with a donwpipe holder
The downpipe is available in 3m lengths – with an intermediate downpipe available of Im

Downpipe holder BB



Fixes the downpipe on the building facade "Click" type locking system Triple fixing possibilities, depending on the type of the facade: two lateral ears, centrally with dowels or vertically with pop-rivets (on brickwall with thermal system and metal walls)

It masks joints between two downpipes

Downpipe connector MB



Combines two cutted downpipes together. Efficient for customers to reduce waste of material/

Pipe branch





Joins two water drainage columns (helps reduce costs by eliminating one of the columns)
Element with an adjustable joint angle
An optimal solution when one drainage column has to be diverted into another direction

Rainwater diverter

EC



Directs water to another route or tank.
Adjustable diverter - possibility to keep it opened, for water collection, or closed for water drainage into the ground

Shoe 60° CE



The final element for water evacuation
The free end features a reinforcing ring
When the purpose of the gutter systems is to connect to the sewage system with a drain connector element, the shoe is no longer required

Drain connector RC



Connects the downpipe directly to the drainage system or decanter, when you don't opt for water evacuation through the shoe 60° Ensures optimal sealing with the sewage system Bottom skirt covers any inaccurate cuts and prevents waste infiltration (leaves, gravel)

Decanter

DE




Directs water directly into the drainage system or other tank Keeps the circulation of warm air from the drainage to the downpipe (in cold weather, prevents water freezing inside the downpipe)

Allows the removal of any accumulated leaves, due to the sieve included


Colour options: gray, brown, black

* For more technical details about our products please visit **www.roofart.eu** or request the **Technical catalogue.**

Choosing the right system




S = (Y/2 + X) * Z





MOUNTING SCHEME FOR RAINWATER

Roof surface (m²)	Dimensions gutter/downpipe (mm)	Positioning of the downpipe
100	125 / 87	
150	150 / 100	
180	125 / 87	
300	150 / 100	

NOW YOU CAN CALCULATE THE AMOUNT OF REQUIRED ELEMENTS, YOU JUST NEED TO ADD THE DIMENSIONS OF THE HOUSE










Simple roof						
JB (X)	A ÷ 3 (m)	=				
*BJ, EJ	X - 1	=				
CJ, CPU	A ÷ 0,8 (m)	=				
CU		=	2 dishes			
RA (Y)	A ÷ 10 (m)	=				
BU	Y × H ÷ 3 (m)	=				
BB***	Y × H ÷ 2 (m)	=				
СВ	Y × 2	=				
PB	Υ	=				
CE	Υ					

Double-pitch roof						
JB (X)	A × 2 ÷ 3 (m)	=				
*BJ, EJ	X - 2	=				
CJ, CPU	A × 2 ÷ 0,8 (m)	=				
CU		=	4 dishes			
RA (Y)	A × 2 ÷ 10 (m)	=				
BU	Y × H ÷ 3 (m)	=				
BB***	Y × H ÷ 2 (m)	=				
СВ	Y × 2	=				
PB	Y	=				
CE	Υ					





Four-pitch roof						
JB	(A+B) × 2 ÷ 3(m)	=				
*BJ, EJ	X - 4	=				
CJ, CPU	(A+B) × 2 ÷ 0,8 (m)	=				
KEB	4 dish					
RA (Y)	(A +B) × 2 ÷ 10 (m)	=				
BU	H × Y ÷ 3 (m)	=				
BB***	H × Y ÷ 2 (m)	=				
СВ	Y * 2	=				
PB, CE	Υ	=				



Complex roof							
JB (X)	(A+B+C+D) ÷ 3 (m)	=					
*BJ, EJ	X - 4	=					
CJ, CPU	(A+B+C+D) ÷ 0,8 (m)	=					
CU, KEB, KIB		= =	CU 4 dish, KEB - 1 dish, KIB - 1 dish				
RA (Y)	(A+B) ÷ 10 (m) = Y1 (C+D) ÷ 10 (m) = Y2 Y1 + Y2 = Y	_					
BU	H × Y ÷ 3 (m)	=					
BB***	H × Y ÷ 2 (m)	=					
СВ	Y × 2	=					
PB	Y	=					
CE	Υ	=					


A - Length of eaves
H - Height up to eaves
S - Distance from the wall to the edge of the roof. If S> 0.9m, use two intermediate downpipes (PB)
B, C, D - lengths of guttering for complex roofs

Installation instructions

* Available in video format on www.roofart.eu/installation-guides



The long-lasting roof



Before mounting the hooks, you should draw a drainage slope towards the place where you will place the pipes. It is preferable to make the slope of the gutter about 2 mm for each meter of its length. The distance between the hooks should not exceed 0.8 m, and the hooks at the ends should be placed 0,1 m from the edge of the roof.




grinder for these jobs will result into the loss of warranty for the entire rainwater system.



It is recommended to mount the gutter so that its outer side is 30-40 mm lower than the imaginary extension of the roof structure. Thus, the flow of water from the roof will not go over the gutter.



Before you mount the brackets (CJ), you should bend them so they match the angle of the roof inclination with a special device, according to the drainage slope.



Mark a spot and use a saw and tinsnips to cut a drainage slot in the gutter, which should not be larger than the diameter of the downpipe.



Two gutters that are to be joined should be placed on the brackets without being fixed. The distance between the edges of the gutters should be approximately 2-3 mm, as the The gutters and the corners (KEB / KIB) have the property to expand and contract according to the temperature variations.



At the internal/ external corners of the building, the KIB/ KEB are mounted in order to connect the two gutters. Sealing is possible thanks to the included brackets from manufacturing on both corner elements.



For the installation of downpipes (BU), attach the downpipe holders (BB) on the wall, one below the other, depending on the type of facade: in two side ears, central with a stud or vertical with poprivets. The maximum distance between two holders will not exceed 2 meters, while for each downpipe at least two support brackets will be used.



Downpipe bends 60° (CB) are mounted on the gutter outlet (RA) and down onto the downpipe (BU). They can be joined through the intermediate downpipe (PB). Measure the distance between the bends "a", add 100 mm to it, for both ends of the intermediate downpipe, each of which enter the bends by 50 mm.



The universal stop (CU) end is fixed manually or using an elastic hammer at the end of the gutter, without using silicon because it destroys the gasket through time.

The long-lasting roof